

PowerBox				Board	FREESTYLE WAVE (PRO)						FREESTYLE WAVE (ES)						MAGIC RIDE			
Size	Length	Area (cm2)	Recomm. Sail	Size	78	84	94	104	114	124	78	84	94	104	114	124	99	109	119	
					<6.2	4.0-6.5	4.5-6.7	4.7-6.9	5.0-7.2	5.3-7.2	<6.2	4.0-6.5	4.5-6.7	4.7-6.9	5.0-7.2	5.3-7.2	4.0-7.0	4.7-7.5	5.0-8.0	
FREESTYLE WAVE (G10 CNC)				THRUSTER SET-UP use with side fins						SINGLE FIN use without side fins										
21	8.3"	182	<5.4	4.0-5.8	<5.6	<5.0	<5.0				<5.4	<5.0	<4.7							
23	9.0"	206	<5.6	5.0-6.2	4.4-6.0	<5.8	<5.8	<5.6			<5.6	<5.6	<5.0	<5.0						
25	9.8"	230	4.0-5.8	5.8-6.2	5.0-6.5	4.7-6.2	4.7-6.2	5.0-5.8	<5.8		5.0-6.2	4.4-6.0	4.5-5.8	<5.8	<5.8					
27	10.6"	254	4.2-6.2		5.8-6.5	5.2-6.7	5.0-6.5	5.0-6.2	<6.2		5.8-6.2	5.0-6.5	4.7-6.2	4.7-6.2	<6.2	<6.2	<5.0			
29	11.4"	279	4.7-6.7			6.0-6.7	5.4-6.7	5.4-6.9	5.0-6.7			5.8-6.5	5.2-6.7	5.0-6.5	5.0-6.7	5.0-6.7	<5.5	<6.0		
31	12.2"	293	5.0-6.9			6.5-6.9	5.8-6.9	5.8-6.9	5.5-7.0				5.2-6.7	5.0-6.5	5.0-6.7	5.0-6.9	<5.5	<6.0	<6.5	
				This fin comes with the board																