

# FREESTYLE WAVE

PowerBox				Board Size	MANOEUVRE / WAVE SETUP						FREERIDE SETUP					
					78	84	94	104	114	124	78	84	94	104	114	124
Size	Length	Area (cm2)	Recomm. Sail	<6.2	4.0-6.5	4.5-6.7	4.7-6.9	5.0-7.2	5.3-7.2	<6.2	4.0-6.5	4.5-6.7	4.7-6.9	5.0-7.2	5.3-7.2	
<b>FREESTYLE WAVE (G10 CNC)</b>				<b>THRUSTER SET-UP</b> use with side fins						<b>SINGLE FIN</b> use without side fins						
21	8.3"	182	<5.4	4.0-5.8	<5.6	<5.0	<5.0			<5.4	<5.0	<4.7				
23	9.0"	206	<5.6	5.0-6.2	4.4-6.0	<5.8	<5.8	<5.6		4.0-5.8	<5.6	<5.0	<5.0			
25	9.8"	230	4.0-5.8	5.8-6.2	5.0-6.5	4.7-6.2	4.7-6.2	5.0-5.8	<5.8	5.0-6.2	4.4-6.0	4.5-5.8	<5.8	<5.8		
27	10.6"	254	4.2-6.2		5.8-6.5	5.2-6.7	5.0-6.5	5.0-6.2	<6.2	5.8-6.2	5.0-6.5	4.7-6.2	4.7-6.2	<6.2	<6.2	
29	11.4"	279	4.7-6.7			6.0-6.7	5.4-6.7	5.4-6.9	5.0-6.7		5.8-6.5	5.2-6.7	5.0-6.5	5.0-6.7	5.0-6.7	
31	12.2"	305	5.0-6.9			6.5-6.9	5.8-6.9	5.8-6.9	5.5-7.0			6.0-6.7	5.0-6.5	5.0-6.7	5.0-6.9	
33	13.0"	331	5.2-7.2				6.4-6.9	6.2-7.2	6.0-7.2				5.8-6.9	5.8-6.9	5.5-7.0	
<b>RIDE (G10 CNC)</b>				<b>THRUSTER SET-UP</b> use with side fins						<b>SINGLE FIN</b> use without side fins						
32	12.6"	297	5.0-7.0				5.8-6.9	5.8-6.9	5.5-6.9			6.0-6.7	5.8-6.9	5.0-7.0	5.0-7.0	
34	13.4"	322	5.2-7.2				6.4-6.9	6.2-7.2	6.0-7.2			>6.5	>6.5	5.2-7.2	5.2-7.2	
36	14.2"	353	5.5-7.5					6.7-7.2	6.7-7.2			>6.7	>6.5	>6.5	>6.5	
<b>WEED WAVE (G10 CNC)</b>										<b>SINGLE FIN</b> use without side fins						
21	8.3"	245	<6.2							<6.2	<6.2	<6.0	<6.0	<6.0	<6.0	
23	9.0"	268	4.7-6.5							4.7-6.5	4.7-6.5	4.7-6.5	4.7-6.5	5.0-6.5	5.0-6.5	
26	10.2"	309	5.4-7.2								6.0-6.5	6.0-6.7	5.4-6.9	5.4-7.2	5.4-7.2	
<b>WEED Freeride (G10 CNC)</b>										<b>SINGLE FIN</b> use without side fins						
31	12.2"	368	6.2-7.7											6.2-7.2	6.2-7.2	

Boards come with: 1x main fin (yellow) + 2x side fins + 2x Slot box covers.

Freeride use (no side fins): a 2cm bigger main fin covers a ~similar wind range compared to use with side fins