

MAGIC MOVE

PowerBox				Board Size	90	100	110
Size	Length	Area (cm2)	Recomm. Sail	4.5-6.4	4.7-6.9	5.0-7.2	
FREESTYLE WAVE							
21	8.3"	182	<5.4				
23	9.0"	206	<5.6	<5.0			
25	9.8"	230	4.0-5.8	4.5-5.8	<5.8		
27	10.6"	254	4.2-6.2	4.7-6.2	4.7-6.2	<6.2	
29	11.4"	279	4.7-6.7	4.7-6.2	5.0-6.5	5.0-6.7	
31	12.2"	305	5.0-7.0	6.0-6.7	5.0-6.5	5.0-6.7	
33	13.0"	331	5.2-7.2		>6.5	5.4-6.9	
RIDE							
32	12.6"	297	5.0-7.0	6.0-6.7	5.8-6.9	5.0-7.0	
34	13.4"	322	5.2-7.2	>6.5	>6.5	5.2-7.2	
36	14.2"	353	5.5-7.5		>6.7	>6.5	
WEED WAVE							
21	8.3"	245	<6.2				
23	9.0"	268	4.7-6.5	4.7-6.4	4.7-6.5	4.7-6.5	
26	10.2"	309	5.4-7.2	6.0-6.7	5.4-6.9	5.4-7.2	
WEED Freeride							
31	12.2"	368	6.2-7.7			6.2-7.2	

This fin (yellow) comes with the board.